# beyerdynamic))))

A 2

KOPFHÖRERVERSTÄRKER
HEADPHONE AMPLIFIER

Bedienungsanleitung

**Operating Instructions** 

2 A 2 – Sicherheit

## 1. Merkmale

- · Diskreter Aufbau der integrierten Audiobauteile
- · Zwei Kopfhörerausgänge, parallel geschaltet
- Lautstärkeregler für beide Kopfhörerausgänge (ALPS-Potentiometer mit Motorsteuerung)
- Zwei Eingänge, davon ein durchgeschleifter Eingang zum Anschluss von Hochpegelsignalquellen (CD-Player, DVD-Player) und Verstärkern
- Fernbedienung für alle Funktionen
- Kopfhörerständer
- Einstellbare Empfindlichkeit und Ausgangsimpedanz
- Umschaltbare Netzspannung für 110 120 V und 220 240 V

## 2. Lieferumfang

- Kopfhörerverstärker A 2
- Fernbedienung RC 2
- Kopfhörerständer
- · Befestigungsset für Kopfhörerständer
- Netzkabel
- · Bedienungsanleitung
- · Sicherheitshinweise

## 3. Sicherheitsinformationen

- 1. Bitte lesen Sie diese Anweisungen.
- 2. Bitte bewahren Sie diese Anweisungen auf.
- 3. Bitte beachten Sie alle Warnhinweise.
- 4. Folgen Sie allen Anweisungen.
- 5. Verwenden Sie dieses Gerät nicht in der Nähe von Wasser.
- 6. Reinigen Sie das Gerät nur mit einem trockenen Tuch.
- 7. Montieren Sie das Gerät nicht neben Hitzequellen wie Heizkörpern, Wärmespeichern, Öfen oder anderen Geräten (auch Leistungsverstärkern), die Hitze abstrahlen.
- 8. Nehmen Sie keine Veränderungen am Netzstecker dieses Gerätes vor. Ein polarisierter Stecker hat zwei Kontakte, von denen einer breiter ist als der andere. Ein geerdeter Stecker hat zwei Kontakte sowie einen dritten Kontakt, der zur Erdung dient. Der breitere Kontakt beziehungsweise der Erdungskontakt dient Ihrer Sicherheit. Wenn der Stecker an dem mit diesem Gerät gelieferten Kabel nicht zur Steckdose am Einsatzort passt, lassen Sie die entsprechende Steckdose durch einen Elektriker ersetzen.
- Sichern Sie das Netzkabel gegen Einquetschen oder Abknicken, insbesondere am Gerät selbst sowie an dessen Netzstecker
- 10. Verwenden Sie nur das vom Hersteller benannte Zubehör für dieses Gerät.
- 11. Trennen Sie das Gerät vom Stromnetz, wenn ein Gewitter aufkommt oder wenn Sie es voraussichtlich für längere Zeit nicht verwenden werden.
- 12. Alle Wartungsarbeiten müssen von hierfür qualifizierten Servicemitarbeitern durchgeführt werden. Eine Wartung ist erforderlich, wenn das Gerät selbst oder dessen Netzkabel beschädigt wurde, Flüssigkeiten oder Gegenstände in das Gerät gelangt sind, das Gerät Regen oder starker Feuchtigkeit ausgesetzt wurde, das Gerät nicht ordnungsgemäß arbeitet oder es heruntergefallen ist.

## Haftungsausschluss

 Die Firma beyerdynamic GmbH & Co. KG übernimmt keine Haftung für Schäden am Produkt oder Verletzungen von Personen aufgrund unachtsamer, unsachgemäßer, falscher oder nicht dem vom Hersteller angegebenen Zweck entsprechender Verwendung des Produkts.

## Standort

- Das Gerät muss so aufgestellt werden, dass der Netzanschluss, Netzschalter und alle Anschlüsse auf der Rückseite des Gerätes leicht zugänglich sind.
- Wenn Sie das Gerät an einen anderen Ort transportieren, achten Sie darauf, dass es ausreichend gesichert ist und niemand durch ein eventuelles Herunterfallen oder Stoßen am Gerät verletzt werden kann.

#### Brandschutz

• Stellen Sie niemals offene Brandquellen (z.B. Kerzen) auf das Gerät.

## Feuchtigkeit / Wärmequellen

- Setzen Sie das Gerät niemals Regen oder hoher Feuchtigkeit aus. Installieren Sie es daher nicht in unmittelbarer Nähe von Swimming Pools, Duschanlagen, feuchten Kellerräumen oder sonstigen Bereichen mit außergewöhnlich hoher Luftfeuchtigkeit.
- Stellen Sie niemals mit Flüssigkeiten gefüllte Gegenstände (z.B. Vasen oder Trinkgläser) auf das Gerät. Flüssigkeiten in den Geräten können einen Kurzschluss verursachen.
- Installieren und betreiben Sie das Gerät auch niemals in unmittelbarer Nähe von Heizkörpern, Beleuchtungsanlagen oder anderen wärmeerzeugenden Geräten.
- Setzen Sie das Gerät niemals direkter Sonneneinstrahlung aus.

#### **Anschluss**

- Verlegen Sie alle Kabel stets so, dass sie nicht durch scharfe Gegenstände geknickt oder gar durchgetrennt werden können.
- Verlegen Sie alle Anschlusskabel so, dass niemand darüber stolpern und sich verletzen kann.
- Schalten Sie bei allen Arbeiten an den Ein- und Ausgängen die Stromzufuhr aus.
- Überprüfen Sie, ob die Anschlusswerte mit der vorhandenen Netzstromversorgung übereinstimmen. Bei Anschluss
  des Systems an die falsche Stromversorgung können ernsthafte Schäden entstehen. Eine falsche Netzspannung
  kann das Gerät beschädigen oder einen elektrischen Schlag verursachen.
- Beachten Sie, dass für verschiedene Netzspannungen entsprechende Netzkabel und Anschlussstecker erforderlich sind.
- Wenn durch das Gerät eine Sicherung defekt oder ein Kurzschluss verursacht wurde, nehmen Sie es vom Netz und lassen Sie es überprüfen und reparieren.
- Fassen Sie das Netzkabel nicht mit nassen Händen an. An den Kontaktstiften darf sich kein Wasser oder Staub befinden. In beiden Fällen könnten Sie einen elektrischen Schlag erleiden.
- Das Netzkabel muss fest angeschlossen sein. Ist es lose, besteht Brandgefahr.
- Ziehen Sie das Netzkabel immer am Stecker vom Netz und/oder vom Gerät niemals am Kabel. Das Kabel könnte beschädigt werden und einen elektrischen Schlag oder Brand verursachen.
- · Setzen Sie das Gerät nicht ein, wenn der Netzstecker beschädigt ist.
- Wenn Sie defektes oder ungeeignetes Zubehör anschließen, kann das Gerät beschädigt werden. Verwenden Sie daher nur die von beyerdynamic lieferbaren oder empfohlenen Anschlusskabel.
- Zum Trennen des Gerätes vom Netz, schalten Sie es aus und ziehen Sie den Netzstecker aus der Netzsteckdose.

#### Reinigung

Reinigen Sie das Gerät nur mit einem leicht feuchtem oder trockenem Tuch. Verwenden Sie niemals Lösungsmittel, da diese die Oberfläche beschädigen.

## Fehlerbeseitigung / Reparatur

- Öffnen Sie nicht eigenmächtig das Gerät.
- Überlassen Sie alle Servicearbeiten nur autorisiertem Fachpersonal.

## 4. Entsorgung




Dieses Produkt darf am Ende seiner Lebensdauer nicht über den normalen Haushaltsabfall entsorgt werden, sondern muss an einem Sammelpunkt für das Recycling von elektrischen und elektronischen Geräten abgegeben werden. Das Symbol auf dem Produkt, der Gebrauchsanweisung oder der Verpackung weist darauf hin.

## 5. Bedienelemente

#### Vorderseite

4



- Hinterleuchtete Standby-Taste.
   Rot = Gerät ist im Standby-Modus.
   Grün = Gerät ist eingeschaltet.
- 2 Infrarotdiode zum Empfang der Signale, die über die Fernbedienung gesendet werden.
- Sopfhöreranschluss, parallel geschaltet, 6,35 mm Stereo-Klinke. Zum Anschluss handelsüblicher Kopfhörer.

## Wichtig:

Da die Kopfhörerbuchsen parallel geschaltet sind, wird die Lautstärke für beide Kopfhörer gemeinsam geregelt. Wir empfehlen daher, unbedingt Kopfhörer mit der gleichen Impedanz zu verwenden, um für beide die gleiche Lautstärke zu erzielen.

- Hinterleuchtete Taste zum Auswählen von Eingang "Input 1" und Aufschalten des Signals des an Eingang "Input 1" angeschlossenen Gerätes.
  Orange = Eingang "Input 1" ist aktiv.
- Hinterleuchtete Taste zum Auswählen von Eingang "Input 2" und Aufschalten des Signals des an Eingang "Input 2" angeschlossenen Gerätes.
  Orange = Eingang "Input 2" ist aktiv.
- 6 Lautstärkeregler zum Einstellen der Lautstärke.




## Warnhinweis/Gehörschutz:

Wir möchten Sie darauf hinweisen, dass zu hohe Lautstärken und zu lange Hörzeiten das Gehör schädigen können. Hörschäden stellen immer eine irreversible Beeinträchtigung des Hörvermögens dar. Drehen Sie daher bitte den Lautstärkeregler vor Inbetriebnahme und beim Wechsel der Audioquellen zurück, da die angeschlossenen Geräte bzw. auch reproduzierte Audiodatenträger sehr unterschiedliche Ausgangspegel haben können.

Achten Sie stets auf eine angemessene Lautstärke. Als Faustformel gilt: je höher die Lautstärke, desto kürzer die Hörzeit. Gemäß der Berufsgenossenschaftlichen Vorschrift für Sicherheit und Gesundheit bei der Arbeit BGV B3 darf die Lärmbelastung z.B. am Arbeitsplatz 85 dB (Zimmerlautstärke) nicht überschreiten. Dies entspricht einer maximal zulässigen Hörzeit von 8 Stunden. Wird die Lautstärke jeweils um 3 dB erhöht, halbiert sich die zulässige Hörzeit, d.h. bei 88 dB beträgt die Hörzeit 4 Stunden, bei 91 dB 2 Stunden usw.

#### Rückseite



Eingang "Input 1", Stereo-Cinchbuchsen für Hochpegelsignalquellen. Input-Buchsen = Anschluss für Audioquelle (CD-Player, DVD-Player usw.)


Audiosignal selbst bei ausgeschaltetem A 2 über Ihre Stereoanlage hören.

- Ourchgeschleifter Ausgang "Output 1" (hart verdrahtet) = Anschluss für Geräte mit Hochpegeleingängen (Stereoverstärker, aktive Lautsprecher usw.)
  Am Ausgang "Output 1" können Sie direkt das Audiosignal vom Eingang "Input 1" abgreifen und an Ihren Stereoverstärker, aktive Lautsprecher oder andere Geräte mit gängigen Hochpegeleingängen weiterleiten. Da das Signal des Eingangs "Input 1" permanent am Ausgang "Output 1" anliegt, können Sie das durchgeschleifte
- Eingang "Input 2" = Anschluss für eine weitere Audioquelle (CD-Player, DVD-Player usw.) oder Verstärker
- Spannungswahlschalter Schalterstellung 230 V: für den Spannungsbereich 220 - 240 V Schalterstellung 115 V: für den Spannungsbereich 110 - 120 V

**Warnung:** Bevor Sie den A 2 an das Stromnetz anschließen, überprüfen Sie bitte, ob der ausgewählte Spannungsbereich mit der ortsüblichen Netzspannung übereinstimmt. Der Anschluss an eine andere Netzspannung bzw. ein Umschalten des Spannungswahlschalters während des Betriebs kann im Gerät einen Kurzschluss verursachen und das Gerät beschädigen.

Netzanschluss Im Lieferumfang ist ein Netzkabel enthalten. Sollte der Stecker des Netzkabels nicht für den ortsüblichen Stromanschluss geeignet sein, erwerben Sie bitte im Fachhandel ein entsprechendes Netzkabel.

## Unterseite



## Ausgangsimpedanzschalter

Stellen Sie die Ausgangsimpedanz entsprechend der Impedanz des verwendeten Kopfhörers ein. Empfohlene Einstellungen:

 $0 \Omega$  = Bei Anschluss von niederohmigen Kopfhörern mit z.B. 16 Ω oder 32 Ω.

100  $\Omega$  = Bei Anschluss von mittel- und hochohmigen Kopfhörern mit z.B. 80  $\Omega$ , 250  $\Omega$  oder 600  $\Omega$ .

## Hinweis:

In beiden Schalterstellungen ist der Kopfhörerausgang des A 2 gegen Kurzschluss geschützt.

Die Verstärkungsfaktoren des A 2 sind so kalibriert, dass beim Anschluss eines Kopfhörers mit 32  $\Omega$  in beiden Schalterstellungen dieselbe Lautstärke erzielt wird.

#### Empfindlichkeitsschalter

Dient zur Anpassung an das angeschlossene Zuspielgerät und den Kopfhörer.


0 dB = Grundeinstellung (Auslieferzustand).

-4 dB = Bei Anschluss von Kopfhörern mit einem hohen Wirkungsgrad oder einem leistungsstarken Zuspielgerät.


+6 dB = Bei Anschluss von Kopfhörern mit einem niedrigen Wirkungsgrad oder einem leisen Zuspielgerät.

## 6. Fernbedienung

#### Vorderseite



#### Rückseite



Der Kopfhörerverstärker A 2 kann auch über die mitgelieferte Fernbedienung gesteuert werden. Über die Tasten sind die im Folgenden beschriebenen Funktionen möglich.

#### Hinweis:

Richten Sie die Fernbedienung auf die Infrarotdiode 2 am Verstärker. Für größtmögliche Reichweite achten Sie darauf, dass der Verstärker keiner direkten Sonneneinstrahlung ausgesetzt ist.

Ein-/Austaste

Zum Ein- oder Ausschalten des am Netz angeschlossenen A 2. Standby-Taste 1 rot: Gerät ist im Standby-Modus. Standby-Taste 1 grün: Gerät ist eingeschaltet.

Mute-Taste

Zum Stummschalten des Kopfhörers.

Je nachdem welcher Eingang aktiv ist, erlischt am A 2 die hinterleuchtete Taste für "Input 1" ④ oder "Input 2" ⑤. Die Stummschaltung kann durch nochmaliges Drücken der Mute-Taste oder durch Verändern der Lautstärke mit dem Lautstärkeregler ⑥ der Fernbedienung deaktiviert werden.

Auswahltaste "Input 1"

Taste zum Auswählen des Eingangs "Input 1" und Aufschalten des Signals des am Eingang "Input 1" angeschlossenen Gerätes.

Taste "Input 1" 4 orange hinterleuchtet: Eingang "Input 1" ist aktiv.

Auswahltaste "Input 2"

Taste zum Auswählen des Eingangs "Input 2" und Aufschalten des Signals des an Eingang "Input 2" angeschlossenen Gerätes.

Taste "Input 2" **5** orange hinterleuchtet: Eingang "Input 2" ist aktiv.

13 Lautstärkeregler

Drücken Sie auf "+", um die Lautstärke zu erhöhen.

Der Lautstärkeregler **6** am A 2 dreht sich nach rechts und die Teste Japut 1" oder Japut 2" am A 2 bliekt erenge.


die Taste "Input  $1^{\circ}$  oder "Input  $2^{\circ}$  am A 2 blinkt orange, solange der Lautstärkeregler der Fernbedienung gehalten wird.

Drücken Sie auf "-", um die Lautstärke zu reduzieren. Der Lautstärkeregler **3** am A 2 dreht sich nach links und die Taste "Input 1" oder "Input 2" am A 2 blinkt orange, solange der Lautstärkeregler der Fernbedienung gehalten wird.

Batteriefach

Zum Einlegen/Wechseln der Batterie (Knopfzelle Li-Mn, CR 2032) öffnen Sie das Batteriefach. Verwenden Sie hierfür eine Münze und drehen Sie den Batteriefachdeckel um 90° entgegen dem Uhrzeigersinn. Um Kratzer zu vermeiden, wickeln Sie die Münze in ein weiches Tuch.

# 7. Anwendungsbeispiel




#### Bedienhinweise zum Anwendungsbeispiel

- Schließen Sie an den Eingang "Input 1" **1** des A 2 einen CD-Player an.
- Schließen Sie den Ausgang "Output 1" 3 des A 2 an den CD-Eingang des Verstärkers an.
- Schließen Sie den Ausgang "Aux Out" oder "Tape Out" des Verstärkers an den Eingang "Input 2" g des A 2 an.
- Schließen Sie einen oder zwei Kopfhörer am Kopfhöreranschluss 3 an. Je nach Wirkungsgrad und Impedanz des Kopfhörers, können Sie die Empfindlichkeit 8 und Ausgangsimpedanz 2 auf der Unterseite des A 2 einstellen.
- Schließen Sie den A 2 über den Netzanschluss am Stromnetz an.
   Warnung: Bevor Sie den A 2 an das Stromnetz anschließen, überprüfen Sie bitte, ob der über den Spannungswahlschalter ausgewählte Spannungsbereich mit der ortsüblichen Netzspannung übereinstimmt. Der Anschluss an eine andere Netzspannung bzw. ein Umschalten des Spannungswahlschalters während des Betriebs kann im Gerät einen Kurzschluss verursachen und das Gerät beschädigen.
- Sobald der A 2 an das Stromnetz angeschlossen wurde, leuchtet die Standby-Taste 1 rot.
- Schalten Sie den A 2 über die Standby-Taste 1 am A 2 oder über die Fernbedienung 10 ein. Die Standby-Taste 1 leuchtet grün und die Taste 4 oder 5 des beim letzten Ausschalten aktiven Eingangs leuchtet orange.
- Sie können nun mit den Tasten 4 oder 5 am A 2 oder über die Tasten 6 oder 7 der Fernbedienung eine von den beiden Audioquellen auswählen, d.h. über die Taste "Input 1" 4 oder 6 wählen Sie den CD-Player bzw. über die Taste "Input 2" 5 oder 7 ein anderes am Verstärker angeschlossenes Gerät wie z.B. TV, DVD-Player, Tuner oder Phono aus.
- Das Signal des Eingangs "Input 1" liegt zusätzlich permanent am Ausgang "Output 1" an. Das bedeutet, Sie können ohne Umstecken das durchgeschleifte Audiosignal selbst bei ausgeschaltetem A 2 über Ihre Stereoanlage hören.
- Stellen Sie die gewünschte Lautstärke mit dem Lautstärkeregler 6 oder über die Fernbedienung 6 ein.
- Soll der Kopfhörer vorübergehend stummgeschaltet werden, drücken Sie die Mute-Taste der Fernbedienung.
   Die orange leuchtende Taste oder se des ausgewählten Eingangs 1 oder 2 erlischt. Die Stummschaltung deaktivieren Sie durch nochmaliges Drücken der Mute-Taste oder durch Betätigen des Lautstärkereglers bei über die Fernbedienung.
- Zum Ausschalten des A 2 drücken Sie auf die Standby-Taste 🕦 am A 2 oder auf die Taste 🚯 der Fernbedienung.
- Eine von einem Microcontroller gesteuerte, intelligente Relaisschaltung sorgt dafür, dass Ihnen beim Umschalten von einer Audioquelle zur anderen, beim Ein- und Ausschalten des A 2 sowie bei einem Stromausfall kein Knacken den Hörgenuss verdirbt oder das Gehör schädigt.

# 8. Montage Kopfhörerständer

Zur Aufbewahrung des Kopfhörers ist im Lieferumfang des Kopfhörerverstärkers A 2 ein Kopfhörerständer enthalten. Diesen können Sie am A 2 montieren.

- Legen Sie das Gerät mit der Oberseite nach unten auf eine weiche Unterlage ganz vorne an die Tischkante.
- Legen Sie die Bohrungen des Kopfhörerständers auf die entsprechenden Bohrungen des Kopfhörerverstärkers A 2. Siehe Zeichnung unten.
- Befestigen Sie den Kopfhörerständer mit den beiliegenden Inbusschrauben. Ziehen Sie die Inbusschrauben mit dem Inbusschlüssel im Uhrzeigersinn fest.



## 9. Technische Daten

Kopfhörerverstärker A 2

 $\begin{tabular}{llll} Frequenzgang ... & 1 Hz - 100 kHz (-1 dB) \\ Fremdspannungsabstand ... & >101 dB (unbewertet) \\ Klirrfaktor ... & 0,001% bei 170 mW/250 <math>\Omega$ 

Eingangsimpedanz . . . . . . . . . . . . . . . . 50 k $\Omega$ 

Ausgangsimpedanz . . . . . . . . . . . . . Kopfhörerausgang 0  $\Omega/100~\Omega$  (umschaltbar)

Leistungsaufnahme (Betrieb) . . . . . <15 W Leistungsaufnahme (Standby) . . . . . <0,45 W

Audioanschlüsse . . . . . . . . . . . . 2 x Line-Eingang, Cinchbuchsen vergoldet

1 x Line-Ausgang, Cinchbuchsen vergoldet 2 x Kopfhörerausgang, Klinkenbuchse 6,35 mm,

vergoldete Kontakte

Fernbedienung RC 2

12 A 2 – Safety

#### 1. Features

- · Discrete design of the integrated audio components
- Two headphone outputs connected in parallel
- Volume control for both headphone outputs (motor controlled ALPS potentiometer)
- Two inputs, one of them is looped-through to connect signal sources with high levels (CD player, DVD player) and amplifiers
- · Remote control for all functions
- · Headphone stand
- · Selectable gain and output impedance
- Switchable supply voltage for 110 120 V and 220 240 V

## 2. Supplied Accessories

- · A 2 Headphone Amplifier
- RC 2 Remote Control
- · Headphone stand
- · Mounting set for headphone stand
- · Power cable
- Manual
- · Safety Instructions

## 3. Safety Instructions

- 1. Read these instructions.
- 2. Keep these instructions.
- 3. Heed all warnings.
- Follow all instructions.
- 5. Do not use this apparatus near water.
- 6. Clean only with a dry cloth.
- 7. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- 8. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- 9. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- 10. Only use attachments/accessories specified by the manufacturer.
- 11. Unplug this apparatus during lightning storms or when unused for long periods of time.
- 12. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

## **Exemption from liability**

 beyerdynamic GmbH & Co. KG will not be liable if any damage, injury or accident occurs due to negligent, incorrect or inappropriate operation of the product.

## Location

- The equipment must be set up so that the mains switch, mains plug and all connections on the rear of the device are easily accessible.
- If you transport the equipment to another location take care to ensure that it is adequately secured and can never be damaged by being dropped or by impacts on the equipment.

#### Fire hazard

• Never place naked flames (e.g. candles) near the equipment.

## Humidity / heat sources

- Never expose the equipment to rain or a high level of humidity. For this reason do not install it in the immediate
  vicinity of swimming pools, showers, damp basement rooms or other areas with unusually high atmospheric
  humidity.
- Never place objects containing liquid (e.g. vases or drinking glasses) on the equipment. Liquids in the equipment could cause a short circuit.
- Do not install near any heat sources such as radiators, heat registers, stoves or other apparatus (including amplifiers) that produce heat.
- · Never expose the equipment to direct sunlight.

#### Connection

- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the
  point where they exit from the apparatus.
- Lay all connection cables so that they do not present a trip hazard.
- Whenever working on the inputs and outputs of the equipment switch off power.
- Check whether the connection figures comply with the existing mains supply. Serious damage could occur due
  to connecting the system to the wrong power supply. An incorrect mains voltage could damage the equipment or
  cause an electric shock.
- · Please note that different operating voltages require the use of different types of power cable and plugs.
- If the equipment causes a blown fuse or a short circuit, disconnect it from the mains and have it checked and repaired.
- Do not hold the mains cable with wet hands. There must be no water or dust on the contact pins. In both cases you could receive an electric shock.
- The mains cable must be firmly connected. If it is loose there is a fire hazard.
- Always pull out the mains cable from the mains and/or from the equipment by the plug never by the cable. The
  cable could be damaged and cause an electric shock or fire.
- Do not use the equipment if the mains plug is damaged.
- If you connect defective or unsuitable accessories, the equipment could be damaged. Only use connection
  cables available from or recommended by beyerdynamic. If you use cables you have made up yourself, all claim
  to warranty is null and void.
- In order to disconnect the receiver from AC power, switch it off and disconnect the power plug from the power socket.

#### Maintenance

• Only clean the equipment with a slightly damp or dry cloth. Never use solvents as these damage the surface.

## Troube shooting and servicing

- Do not open the equipment without authorisation. You could receive an electric shock. There are no user-serviceable parts inside.
- Leave all service work to authorised expert personnel.

# 4. Disposal




This symbol on the product, in the instructions or on the packaging means that your electrical and electronic equipment should be disposed at the end of its life separately from your household waste. There are separate collection systems for recycling in the EU. For more information, please contact the local authority or your retailer where you purchased the product.

14 A 2 – Operation

## 5. Controls and Indicators

#### Front view



Backlit standby button.
 Red = Device is in standby mode.
 Green = Device is turned on.

- 2 Infrared diode to receive the signals, which are transmitted via the remote control.
- Headphone sockets, connected in parallel, 1/4" stereo jack (6.35 mm). In order to connect standard headphones.

## Important:

As the headphone sockets are connected in parallel, the volume is controlled for both headphones. Therefore, we recommend using only headphones of the same impedance to achieve the same volume for both headphones.

- Backlit button to select input 1 and transmitting the signal of the device connected to input 1. Orange = Input 1 is active.
- Backlit button to select input 2 and transmitting the signal of the device connected to input 2. Orange = Input 2 is active.
- 6 Volume control to adjust the volume.




#### Warning/hearing protection:

We would like to point out that listening at high volumes over a long period of time may damage your hearing irreversibly. Therefore, reduce the volume before putting into operation and when changing the audio source, as the connected devices or reproduced audio data can have very different output levels.

Make sure that the set volume is not too high. Rule of thumb: The higher the volume, the shorter the time of listening. According to employer's regulations for safety and health the noise exposure e.g. when working should not exceed 85 dB (low volume). This is an allowed time of listening of 8 hours at maximum. If the volume is increased by 3 dB, the allowed time of listening is halved, i.e. with 88 dB the time of listening is 4 hours, with 91 dB 2 hours and so on.

#### Rear View



- Input 1, stereo RCA phono sockets for signal sources with high levels.
  Input sockets = for the connection of audio sources (CD player, DVD player etc.)
- Sopped-through output 1 (hard-wired) = for the connection of devices with high level inputs (stereo amplifiers, active loudspeakers etc.)

At the output 1 you can pick up the audio signal from input 1 ② and route it to your stereo amplifier, active loudspeakers or other devices with standard inputs for high levels. As the signal of the input 1 ② is permanently available at output 1, you can listen to the looped-through audio signal via your hi-fi system, even when the A 2 is turned off.

- 9 Input 2 = for the connection of another audio source (CD player, DVD player etc.) or amplifier
- Voltage selector switch

Position of the switch 230 V: to select the voltage range of 220 - 240 V Position of the switch 115 V: to select the voltage range of 110 - 120 V


**Warning:** Before connecting the A 2 to the mains, please check if the selected voltage range corresponds to the local mains voltage. If you connect the device to a different mains voltage or if you change the position of the voltage selector switch during operation, a short-circuit can occur inside the device and cause damage to the device.

Mains connection

The A 2 is supplied with a power cable. If the connector of the power cable is not suitable for the local power outlet, please purchase an appropriate power cable at your local dealer.

16 A 2 – Operation

## **Bottom**



## Output impedance switch

Select the output impedance according to the impedance of the headphone you are using. Recommended settings:

 $0 \Omega$  = When connecting headphones with a low impedance such as 16  $\Omega$  or 32  $\Omega$ .

100  $\Omega$  = When connecting headphones with a middle or high impedance such as 80  $\Omega$ , 250  $\Omega$  or 600  $\Omega$ .

#### Note:

In both settings the headphone output on the A 2 is protected against short-circuit.

The amplification factors of the A 2 are calibrated in a way that in both settings the same volume is achieved when connecting a headphone with an impedance of  $32~\Omega$ .

#### Gain switch

To adapt the gain to the connected player and the headphone.


0 dB = Base setting (factory default setting).

-4 dB = When connecting headphones with a high efficiency or a high-performance player.


+6 dB = When connecting headphones with a low efficiency or a quiet player.

## 6. Remote Control





Rear View



The A 2 headphone amplifier can also be controlled via the supplied remote control. The buttons allow the function described below.

#### Note:

Direct the remote control at the infrared diode ② of the amplifier. To achieve a wide range, please make sure that the amplifier is not exposed to direct sunlight.

- On-off button
  - To turn on or off the A 2 which is connected to the mains. Standby button 1 red: Device is in standby mode. Standby button 1 green: Device is turned on.
- Mute button

To mute the headphone.

Depending on the active input, the backlit button of the A 2 for input 1 3 or input 2 5 will go out.

Mute can be deactivated by pressing the mute button once again or by changing the volume with the volume control (3) of the remote control.

Selector button "Input 1"

Button to select the input 1 and to transmit the signal of the device connected to input 1 on the A 2.

Orange backlit button "Input 1" 4: Input 1 is active.

Selector button "Input 2"

Button to select the input 2 and to transmit the signal of the device connected to input 2 on the A 2.

Orange backlit button "Input 2" 5: Input 2 is active.

Volume control

Press "+" to increase the volume.

The volume control **6** on the A 2 will turn to the right and the button for input 1 or input 2 on the A 2 will flash orange as long as the volume control of the remote control is pressed.

Press "-" to reduce the volume.


The volume control **6** on the A 2 will turn to the left and the button for input 1 or input 2 on the A 2 will flash orange as long as the volume control of the remote control is pressed.

Battery compartment

In order to insert/replace the battery (round cell Li-Mn, CR 2032), please open the battery compartment. Use a coin to turn the cover of the battery compartment 90° anticlockwise. In order to avoid scratches, wrap a soft cloth around the coin.

18 A 2 – Operation

# 7. Example of Application



## Operating Instruction for the Example of Application


- Connect a CD player to the input 1 7 on the A 2.
- Connect the output 1 (3) on the A 2 to the CD input of the power amplifier.
- Connect the "AUX Out" or "Tape Out" output of the power amplifier to the input 2 3 on the A 2.
- Connect one or two headphones to the headphone connection 3. Depending on the efficiency and the impedance
  of the headphone, select the gain 3 and the output impedance 2 at the bottom of the A 2.
- Connect the A 2 via the mains connection to the mains.
   Warning: Before connecting the A 2 to the mains, please check if the voltage range selected with the voltage selector switch corresponds to the local mains voltage. If you connect the device to a different mains voltage or if you change the position of the voltage selector switch voltage or if you change the position of the voltage selector switch voltage operation, a short-circuit can occur inside the device and cause damage to the device.
- Turn on the A 2 by pressing the standby button 1 on the A 2 or the button 10 of the remote control. The standby button 10 will illuminate green and the button 10 or 15 will illuminate orange, depending on which input was active when the A 2 was turned off.
- Now you can select one of the two audio sources with the buttons on the A 2 or with the buttons of the remote control, i.e. with the button for input 1 or you select the CD player or with the button for input 2 or you select another device connected to the amplifier such as a TV, DVD player, tuner or phono player.
- The signal of input 1 7 is also permanently available at output 1 3. This means you can listen to the looped-through audio signal via your hi-fi system, even when the A 2 is turned off.
- Select the desired volume with the volume control 6 or via the remote control 8.
- If the headphone is to be muted temporarily, press the mute button 6 of the remote control. The orange illuminating button 4 or 5 of the selected input 1 or 2 will go out. Deactive mute by pressing the mute button 5 once again or by pressing the volume control 6 of the remote control.
- In order to turn off the A 2 press the standby button 1 on the A 2 or the button 4 of the remote control.
- An intelligent, microprocessor-controlled relay ensures silent switching between the two different audio sources
  and avoids unpleasant noise or damage to your hearing should a power failure occur or when turning the A 2 on
  or off.

20 A 2 – Operation

## 8. How to Mount the Headphone Stand

The A 2 headphone amplifier is supplied with a headphone stand for storing the headphone. You can mount this stand to the A 2.

- Put the device upside down on a soft pad to the very front on the edge of a table.
- Make sure that the holes of the headphone stand match the holes of the A 2 headphone amplifier. Refer to the drawing below.
- Attach the headphone stand with the supplied Allen screws. Tighten the Allen screws by turning the Allen key clockwise.



# 9. Technical Specifications

A 2 Headphone Amplifier

 $\begin{tabular}{lll} Frequency response. & 1 Hz - 100 kHz (-1 dB) \\ Signal-to-noise ratio & >101 dB (unweighted) \\ T.H.D. & 0.001\% at 170 mW/250 $\Omega$ \\ \end{tabular}$ 

Input impedance. . . . . . . . . . . . . . . . . . 50 k $\Omega$ 

Output impedance . . . . . . . . . . . . . . . Headphone output 0  $\Omega/100~\Omega$  (switchable)

170 mW / 250 Ω 150 mW / 32 Ω

Channel separation L/R . . . . . . . . . . . . >89 dB

Power consumption (operation) . . . . <15 W Power consumption (standby) . . . . <0.45 W

Audio connections. . . . . . . . . . . . . . 2 x line input, gold-plated RCA phono sockets

 $1\ \mbox{x}$  line output, gold-plated RCA phono sockets

2 x headphone output, 1/4" stereo jack (6.35 mm), gold-plated contacts

RC 2 Remote Control



# EC-DECLARATION OF CONFORMITY

Application of

Council directive: 2004/108/EC

Electromagnetic Compatibility

2006/95/EC

Low Voltage Directive

Standards to which

EN 55013:2001+A1:2003 +A2:2006

6 Emission

Conformity is Declared:

EN 55020:2007+A11:2011

Immunity

EN 60065/A12:2011

Safety

Manufacturer's Name:

beyerdynamic GmbH & Co. KG

Manufacturer's Address:

Theresienstrasse 8, 74072 Heilbronn, Germany

Type of Equipment:

Headphone Amplifier

Model Numbers:

Α2

I, the undersigned, as an employee of beyerdynamic, hereby declare that the equipment specified conforms to the above Directive and Standards.

Manufacturer's Signature:

Word Roth
Ulrich Roth

Date:

Full Name:

1. April 2014

Position:

Director of R&D

# beyerdynamic)



# **DECLARATION OF CONFORMITY**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Manufacturer: beyerdynamic GmbH & Co. KG

Theresienstrasse 8

D- 74072 Heilbronn, Germany

U.S. Responsible Party: beverdynamic, Inc.

56 Central Avenue

Farmingdale, NY 11735, USA

**Contact Person:** Wolfgang Luckhardt, Managing Director

Phone: Tel. (631) 293 3200

Fax: (631) 293 3288

Model/Type: Headphone Amplifier

A 2

Classification: Class B Digital Device

We hereby declare that the equipment bearing the trade name and model number specified above was tested conforming to the applicable FCC rules under the most accurate measurement standards possible, and that the necessary steps have been taken and are in force to assure that production units of the same equipment will continue to comply with the Commission's requirements.

Manufacturer's Signature:

Wird Roll April 1, 2014
U. Roth, Director of R&D

Responsible Party's Signature:

W. Luckhardt, General Manager

beyerdynamic GmbH & Co. KG Theresienstr. 8 | 7 4072 Heilbronn – Germany Tel. +49 (0) 7131 617 - 0 | Fax +49 (0) 7131 617 - 204 info@beyerdynamic.de | www.beyerdynamic.com

